LED WORK LIGHT INSTALLATION INSTRUCTIONS

Preliminary Steps

- 1.Read all instructions carefully and study diagrams before installing lights.
- 2. Check with state and local authorities for laws governing usage and proper mounting of auxiliary lamps.
 - 3. Disconnect ground connection from battery (marked "-") to avoid accidental short circuits before attempting to connect electrical wires.
 - 4. Route new wires along existing wiring. Tape as necessary to correct slack.
 - 5. When running wires through the firewall, keep them away from moving parts.

Mounting Lights

- 1.Drill holes for screw placement on the surface where you would like to fix the light.
- 2.Use the bolt to fasten the lamp, add the locking washer and tighten the bolt.
 - 3. Route new wires along existing wiring. Tape as necessary to correct slack.
 - 4. When running wires through the firewall, keep them away from moving parts.

Wire Functions

Black: Ground "-"

Red: Working light "+"
White: Position light "+"

Yellow: Cable to switch position light color "+"

Reset position light color to yellow: Keep Black to "-", White to "+". At the same time, yellow wire to "+" for 3 seconds.

Warning:

- 1. Work under the specified voltage (DC9-30V)
- 2. This light becomes hot under continuous use. Don't remove or touch the casting for at least 30 minutes after turning the lamp off.
- 3. Keep heat-sink clean and exposed to maintain air flow.

