

LUMARY

EDGE HL 450

BRUKERMANUAL

1. Produktoversikt / innhold i esken

Modellnavn: Lumary Edge HL 450

Modell varenummer: L1401

Innhold i esken:

- Lumary Edge HL 450 hodelykt
- USB-C ladekabel
- Brukermanual

*veggglader følger ikke med.



Batteri

Produktet leveres med et oppladbart

Li-ion polymerbatteri, 3.7V 1200mAh.

Lad produktet med medfølgende USB-C-kabel.

Bruk kun CE-merket USB-strømkilde med 5V DC utgang.

2. Tekniske spesifikasjoner

Lyskilder: Front COB + side-LED

Lysstyrke: COB 100-450 lm, LED 50-100 lm

Lysrekkevidde: maks 20 m

Batteri: 1 x 3,7V 1200mAh oppladbart Li-ion polymerbatteri inkludert

Batteritid: 2-6 t for COB, 3-8 t for LED

Lading: USB-C

Inngang: 5V DC / 1A

USB-C-kabel inkludert. Veggglader følger ikke med.

Ladeindikator: Rødt lys under lading, grønt lys når fulladet.

Materiale: Gummi

Mål: 311,5 x 38 x 23,5 mm

Vekt: 93,3 g inkludert batteri

3. Bruk / lysmoduser

Lysmoduser

Trykk på På/Av-knappen for å bytte mellom:

1. Front stripelys/COB kald hvit - høy
2. Front stripelys/COB kald hvit - lav
3. Front stripelys/COB varm hvit
4. Side-LED hvit - høy
5. Side-LED hvit - lav
6. Av

Skjult strobemodus:

Hold Av/på-knappen inne i 2 sekunder.

Bevegelsessensor:

Trykk på knappen med sensorsymbolet for å aktivere eller deaktivere sensormodus.

Sensormodus innebærer at du kan kontrollere

lyset ved å bevege hånden foran sensoren på siden av hodelykten.

4. Lading

Lading

Slå av hodelykten før lading. Koble den medfølgende

USB-C-kabelen til ladeporten og til en

CE-merket USB-strømkilde med 5V DC-utgang.

Anbefalt input er 5V DC / 1A.

Ladeindikatoren lyser rødt under lading og grønt

når batteriet er fulladet. Koble fra kabelen når ladingen er ferdig.

Ikke bruk produktet hvis kabel, ladeport eller produkt er skadet.

5. Sikkerhetsinformasjon

ADVARSEL om LED-lys

Ikke se direkte inn i LED-lyset. Sterkt lys kan være ubehagelig eller skadelig for øynene. Ikke rett lyset direkte mot øynene til mennesker eller dyr.

Barn skal kun bruke produktet under tilsyn av voksen.

Batterisikkerhet

Ikke kortslutt batteriet. Ikke åpne, punktéer, knus eller kast produktet/batteriet i ild.

Ikke bruk produktet hvis batteriet eller produktet er skadet, hovens, lekker eller blir unormalt varmt.

Ikke utsett produktet for høy varme, direkte sollys over lengre tid eller ekstreme temperaturer.

Oppbevares tørt og kjølig når det ikke er i bruk.

6. Avfallshåndtering

Produktet inneholder batteri og skal ikke kastes i

restavfall. Levér produktet som EE-avfall/batteriavfall til godkjent returpunkt i henhold til lokale regler.

LUMARY

EDGE HL 450

USER MANUAL

1. Product Overview / Box Contents

Model name: Lumary Edge HL 450

Model number: L1401

Box Contents:

- Lumary Edge HL 450 Headlamp
- USB-C charging cable
- User manual

*wall charger not included.



Battery

This product is supplied with a rechargeable 3.7V 1200 mAh Li-ion polymer battery. Charge the product using the included USB-C cable. Only use a CE-certified USB power source with a 5V DC output.

2. Technical Specifications

Light sources: Front COB + Side LED

Lumen: COB 100-450 lm, LED 50-100 lm

Beam distance: Up to 20 m

Battery: 1 x 3.7V 1200mAh rechargeable Li-ion polymer battery (included)

Runtime: 2-6 h (COB) / 3-8 h (LED)

Charging: USB-C

Input: 5V DC / 1A

USB-C charging cable included. Wall charger not included.

Charging indicator: Red while charging, green when fully charged.

Material: Rubber

Dimensions: 311.5 x 38 x 23.5 mm

Weight: 93.3 g (including battery)

3. Operation / Lighting Modes

Lighting Modes

Press the On/Off button to cycle through the following modes:

1. Front light strip/COB cold white - high
2. Front light strip/COB cold white - low
3. Front light strip/COB warm white
4. Side LED white - high
5. Side LED white - low
6. Off

Hidden Strobe Mode:

Press and hold the On/Off button for 2 seconds.

Motion Sensor:

Press the button with the sensor icon to enable or disable motion sensor mode.

In Sensor Mode you can control the light by passing your hand over the sensor at the side of the headlamp.

4. Charging

Turn off the headlamp before charging. Connect the supplied USB-C cable to the charging port and to a CE-certified USB power source with a 5V DC output. The recommended input is 5V DC / 1A.

The charging indicator will illuminate red while charging and green when the battery is fully charged. Disconnect the charging cable once charging is complete.

Do not use the product if the charging cable, charging port, or the product itself is damaged.

5. Safety Information

LED Light WARNING

Do not look directly into the LED light.

The high-intensity light may cause discomfort or eye damage. Never shine the light directly into the eyes of people or animals.

Children should only use this product under adult supervision.

Battery Safety

Do not short-circuit the battery.

Do not open, puncture, crush, or dispose of the product or battery in fire.

Do not use the product if the battery or product is damaged, swollen, leaking, or becomes unusually hot.

Do not expose the product to excessive heat, prolonged direct sunlight, or extreme temperatures. Store the product in a cool, dry place when not in use.

6. Disposal

This product contains a battery and must not be disposed of with household waste.

Dispose of the product as electronic waste (WEEE) and battery waste at an approved recycling facility in accordance with local regulations.

Importer/Contact Information

Victory Norway AS

Østre Lone Lier 84, 4642 Søgne, NORWAY

support@lumary.no

www.lumary.no

L1401