Multifunction Bluetooth Controller

Package includes：
. 1* Control Box
. 1* Controller
. 1* Network cable with RJ connector
. 6* DT connectors
. 2* 3M straps
. 2* Screws

Warning: Do not use wire control when the RJ connect port has water inside.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help

LUMARY

OPERATION INSTRUCTION
Multifunction Bluetooth Controller

V7600

Specifications

120mm
72mm
31mm

Remote Control

224mm
197mm
120.2mm
44.5mm
158mm
Φ165mm

Current: Input 20A/560W Max - 24VDC， 20A/270W Max - 13.5VDC
Output: 20A Max on D1/D2 (ports for Hi/Lo beam / warning light), 10A Max on D3/D4 (ports for other lights), Max 560W/port - 24VDC， Max 270W/port - 13.5VDC
Voltage: 10-30V DC
Control distance: Above 50m for remote control,
                 Above 12m for App control
IP rated: IP67, Potting process
Overload protection

This document provides all the necessary information to allow your product to be properly and safely installed. Before beginning the installation and operation of your new product, the installation technician and operator must read this manual completely.

Function

This device complies with part 15 of the FCC Rules. OPeration is subject to the following two conditions:(1)This device may not cause harmful interference,and(2)this device must accept any interference received,including interference that may cause undesired operation

1. Wire control, Remote control, App on smart phone
   Connect the RJ connector for wire control
   Disconnect the RJ connector for remote control
   Down load the App for phone control

ios   Android

2. Available for all Warning light, Driving light, Work light.

Driving Light
◉ On/Off
◉ High/Low Beam Control

Work Light
◉ On/Off

Warning Light
◉ On/Off
◉ Mode Control

3. Button Function : Turn on the controller first.
   D1/D2 for Driving light
   D3/D4 for Work light
   W1/W2 for Warning light
   ⊒⫶ Hi/Lo Beam Control
   ◁⫶ Mode Control

4. Connecting ports of the box

## Operation

Warning light   Driving light   Work light

Switching between the App and Remote Control to control different products according to your preferences.

App   BLUETOOTH   Controller

Turn on the controller first.

Long press these two buttons

Remark :

1. Controller : Factory seting has been coded. If you find the controller can not match the box, long press both sides buttons of the controller 15s, once you turn on the controller. When all lights flash, then coding successful.

2. App: Turn on the bluetooth/Open the app on you phone, then you can control the box with phone. If the app doesn't work, long press both sides buttons of the controller 5s-10s, while connnecting the controll with the box with network cable. When the indicators light up, then reset